

S.M.S.L

AD18

深圳市双木三林电子有限公司

100mm

安全注意事项

为了确保最好的性能,请仔细阅读本说明书,并妥善保管以备日后查阅。

警告

- ① 请将本音响系统安装在通风良好、阴凉、干燥、干净的位置,远离直射阳光、热源、振动、灰尘、潮湿或寒冷。
- ② 不要将本机从温度反差大的寒冷地方突然搬到温热地方,也不要将本机放置在非常潮湿的环境里(例如放置有加湿器的房间),以免本机内部结露,因为结露可能导致触电,火灾而损坏本机或造成人身伤害。
- ③ 本机的上面,请不要放置下列物品:
 - 其他装置。因为这样有可能会导致损坏或导致本机表面变色。
 - 可燃物品(例如蜡烛)。因为这样有可能导致火灾而损坏本机或造成人身伤害。
 - 装有液体的容器。因为有容器倒反,液体流淌的可能,如此有可能导致用户触电或损坏本机。
- ④ 不要在本机上面覆盖报纸,台布,窗帘等,以免妨碍散热。如果本机内部温度过高,则有可能导致火灾,损坏本机或造成人身伤害。
- ⑤ 不要用化学溶剂清洗本机,否则会损伤表面涂层。请使用干净的布匹。
- ⑥ 不要试图自行改造或修理本机。如果需要任何服务,请就近与有资格的双木三林维修人员联系。不管有任何理由,都没有打开机壳的必要。
- ⑦ 如果打算长时间不使用本机(比如度假时),请从墙壁交流电源插座上断开电源线的连接。
- ⑧ 搬动本机前,请从墙壁电源插座上断开电源线的连接。
- ⑨ 请务必使用本机附带的AC适配器。使用附带的AC适配器以外的适配器可能导致火灾或损害本机。
- ⑩ 为了加强对本产品的保护,在雷电期间,或无人管理时以及长时间不使用时,请将电源线从墙壁上的电源插座上拔下。这样将防止该产品在闪电和电网出现电涌时受到损害。

产品特点

AD18为多功能功率放大器和耳机放大器。具备六种输入分方式分别为USB,同轴,模拟,蓝牙和两路光纤;蓝牙采用高规格的蓝牙4.2方案;功放采用了TI德州仪器的DSP+功放组合;耳放采用了独立耳放电路;内置双木三林专利音效SDB(SMLS Dynamic Bass)。

SDB介绍:

双木三林公司专业的音效,能有效的提升声音的还原度,此音效不只对低音进行提升。同时还会根据当前的音乐信号对高低音进行动态调节,以达到最佳的欣赏效果!

技术参数

输入方式:	THD+N:	信噪比:	USB兼容性:	位深:	采样率:	功放输出功率:	耳放输出功率:	功放消耗功率:	待机功率:
喇叭	0.04%	喇叭	windows XP/7/8.1/10	24bit	44.1KHz-96KHz	4欧	32欧	50W	0.8W
耳机	0.008%	耳机	44.1KHz-192KHz	24bit	44.1KHz-96KHz	64欧	64欧	80W+80W	
						150欧	150欧	26mW@THD=0.02%	
								11mW@THD=0.02%	

第一次操作AD18时,先按A键。

部件介绍

用于连接的电缆

操作说明

功能键在播放界面下长按关机,在菜单界面下,长按返回播放界面,短按切换菜单。

输入方式菜单(图2)

EQ手动调节菜单(图5/6)

恢复出厂设置

机器在未通电状态下,按住开机键再通电,直到显示屏显示logo之后,松开按键。

NFC连接说明

恢复出厂设置

机器在未通电状态下,按住开机键再通电,直到显示屏显示logo之后,松开按键。

等边三角形中有箭头闪电标号的图形表示警告使用者在产品内有非绝缘的“危险电压”,可能会对人类造成很大的电击危险。

等边三角形中有感叹号的图形表示警告使用者该设备在操作与维护(维修)方面应严格按照所附设备说明书。

仅适用于海拔2000m以下地区安全使用。

仅适用于非热带气候条件下安全使用。

深圳市双木三林电子有限公司
地址: 深圳市宝安区福永街道和平骏丰工业园B6栋8楼
电话: +86-755-27444178
<http://www.smsl-audio.com/>

S.M.S.L

AD18

Shenzhen ShuangMuSanLin Electronics Co., Ltd.

100mm

Safety Notes

To assure the best performance, please read this manual carefully. Keep it in a safe place for future reference.

Warning

- ① Install this unit in a well ventilated, cool, dry, clean place-away from direct sunlight, heat sources, vibration, dust, moisture or cold. Using the advanced CSR BT 4.2 as bluetooth solution.
- ② Do not expose this unit to sudden temperature changes from cold to hot, and do not locate this unit in an environment with high humidity [i.e. a room with a humidifier] to prevent condensation inside this unit, which may cause an electrical shock, fire, damage to this unit, or personal injury.
- ③ On the top of this unit, do NOT place:
 - Other components, as they may cause damage or discoloration on the surface of this unit.
 - Burning objects (i.e. candles), as they may cause fire , damage to this unit , or personal injury.
 - Containers with liquid in them, as they may fall and liquid may cause electrical shock to the user or damage to this unit.
 - Do not cover this unit with a newspaper, tablecloth, curtain , etc, in order not to obstruct heat radiation. If the temperature inside this unit rises, it may cause fire, damage to this unit, or personal injury.
 - Do not use force on switches, knobs, and/or cords.
 - Use a clean, dry cloth.
 - Do not attempt to modify or fix this unit. Contact qualified SMLS service personnel when anyservice is needed. The cabinet should never be opened for any reason.
 - When not planning to use this unit for long periods of time (i.e. when going on vacation), disconnect the power cable from the AC wall outlet.
 - Before moving this unit, disconnect the power cable from the wall outlet.
 - Be sure to use the AC adaptor supplied with this unit. Using an AC adaptor other than the one provided may cause fire or damage to this unit.
 - For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet. This will prevent damage to the product due to lightning and power-line surges.
- ④ Note

The plug severed from the mains lead must be destroyed, as a plug with bare flexible cord is hazardous if engaged in a live socket outlet.

AD-18 Features

AD18 is a multi-functional power amplifier with headphone amplifier. Up to six kinds of input including USB, coaxial, analog, bluetooth and two optical jacks.

Specifications

Input:	THD+N:	SNR:	USB compatibility:	Bit depth:	Sampling rate:	Amplifier power:	headphone amplifier power:	Amplifier consumption:	Standby power:
Speakers	0.04%	Speakers	windows XP/7/8.1/10	24bit	44.1KHz-96KHz	40W	4Ω	50W	0.8W
Headphones	0.008%	Headphones	44.1KHz-192KHz	24bit	44.1KHz-96KHz	80W+80W	32Ω	32mW@THD=0.04%	
							64Ω	26mW@THD=0.02%	
							150Ω	11mW@THD=0.02%	

Part Names and Functions

Cables used for connections

Operation

Function Key: Long press to switch off unit. When menu display, Long press to return to desktop and short press to switching menu.

Output mode (figure 3)

Font color change (figure 7)

Factory Reset:

Long-Press power key without power input first, then power on the unit, until screen shows LOGO.

Remote controller

NOTE

Press A button before remote AD18 for the first time.

NFC connection instruction

AD18 build-in NFC function. Please make sure that your phone NFC is on when you connect with it. AD18 will recognize phone when phone NFC area get close and induce to AD18 NFC area.

Notes: Please make sure your phone get NFC before you want to use NFC function from this machine. Otherwise, it will be unable to use NFC function.

Shenzhen ShuangMuSanLin Electronics Co., Ltd.
Address: 8th Floor B4 Building JunFeng Industrial Park, Fuyong town, BaoAn District Shenzhen, China
Tel: +86-755-27444178
<http://www.smsl-audio.com/>